



CODING TABLE

This table supplements information contained in the chart to which it is associated. In spite of the fact the classification of waypoints (fly-by / flyover), courses, distances, altitudes, level and speed restrictions are mandatory, the providers may use the information as they find appropriate in order to code procedures. In other words, in case any particular coding is applied, it is mandatory for it to reflect the procedure published in the chart.

Identification	Aerodrome	Chart Code	AIRAC AMDT
SID RNAV MOXOB 2B RWY 11R	BRASÍLIA / Presidente Juscelino Kubitschek, INTL (SBBR)	SBBR_SID_02U	25 MAY 17

Seq	Transition	Path Terminator	Navaid / Fix / WPT	Type / Function	Flyover (Y/N)	Navaid	Course Mag (True)	Dist (NM)	Turn (L/R)	IAS (KT)	Altitude (FT)	Gradient (%)	Perform.
RWY 11R													
010	Runway	VA	---	---	---	---	107 (086.2)	---	---	---	+4100	---	RNAV 1 or RNP 1
020	Runway	DF	LIVEV	---	N	---	---	---	R	---	-FL090	---	RNAV 1 or RNP 1
RWY 11R													
010	Common	IF	LIVEV	---	N	---	---	---	---	---	-FL090	---	RNAV 1 or RNP 1
020	Common	TF	BR051	---	N	---	287 (266.3)	14.7	---	---	+FL110	---	RNAV 1 or RNP 1
030	Common	TF	MOXOB	---	N	---	287 (265.7)	4.4	---	---	+FL130	---	RNAV 1 or RNP 1
TRNS TIPTU													
010	Enroute	IF	MOXOB	---	N	---	---	---	---	---	+FL130	---	RNAV 1 or RNP 1
020	Enroute	TF	TIPTU	---	N	---	286 (265.5)	28.3	---	---	---	---	RNAV 1 or RNP 1
TRNS SIREM													
010	Enroute	IF	MOXOB	---	N	---	---	---	---	---	+FL130	---	RNAV 1 or RNP 1

020	Enroute	TF	SIREM	---	N	---	246 (225.0)	38.7	---	---	---	---	RNAV 1 or RNP 1
TRNS ROMIK													
010	Enroute	IF	MOXOB	---	N	---	---	---	---	---	+FL130	---	RNAV 1 or RNP 1
020	Enroute	TF	SIREM	---	N	---	246 (225.0)	38.7	---	---	---	---	RNAV 1 or RNP 1
030	Enroute	TF	ROMIK	---	N	---	207 (186.0)	40.3	L	---	---	---	RNAV 1 or RNP 1
TRANS GNV													
010	Enroute	IF	MOXOB	---	N	---	---	---	---	---	+FL130	---	RNAV 1 or RNP 1
020	Enroute	TF	SIREM	---	N	---	246 (225.0)	38.7	---	---	---	---	RNAV 1 or RNP 1
030	Enroute	TF	GNV	---	N	---	281 (260.6)	33.0	R	---	---	---	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
LIVEV	S 16:04:11.40W 47:50:39.00
BR051	S 16:05:08.40W 48:05:49.80
MOXOB	S 16:05:28.20W 48:10:20.40
TIPTU	S 16:07:43.80W 48:39:37.80
SIREM	S 16:33:00.60W 48:38:46.80
ROMIK	S 17:13:13.20W 48:43:07.80
GNV	S 16:38:27.00W 49:12:40.00

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
11R	S 15:52:43.30 / W 47:54:33.26	3417.0

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
=	MANDATORY
	RECOMMENDED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT