


CARTA DE ESTACIONAMENTO DE AERONAVE (PDC)

AIRCRAFT PARKING/
DOCKING CHART (PDC)

ANÁPOLIS / Base Aérea de Anápolis, MIL (SBAN)
GO-BRASIL

ARP 16 14 19 W048 58 20

ELEV 3732'



CHANGES: LAYOUT.

COORDENADAS DOS PONTOS DE ESTACIONAMENTO PARKING SPOT COORDINATES				
PONTO SPOT	COORDENADAS COORDINATES	ACL	PONTO SPOT	COORDENADAS COORDINATES
	PÁTIO/APRON 1A			PÁTIO/APRON 1B
1	S16 14 25 00/W048 58 12 00		6	S16 14 17 00/W048 58 08 00
2	S16 14 23 00/W048 58 13 00		7	S16 14 18 00/W048 58 06 00
3	S16 14 24 00/W048 58 11 00		8	S16 14 16 00/W048 58 08 00
4	S16 14 22 00/W048 58 12 00		9	S16 14 17 00/W048 58 06 00
5	S16 14 23 00/W048 58 10 00		10	S16 14 15 00/W048 58 07 00
5A	S16 14 22.08/W048 58 10.08	3735'	11	S16 14 17 00/W048 58 05 00
5B	S16 14 22.08/W048 58 10.08	3735'	12	S16 14 15 00/W048 58 06 00
6A	S16 14 22.02/W048 58 10.08	3735'	13	S16 14 16 00/W048 58 04 00
6B	S16 14 22.02/W048 58 10.08	3735'	14	S16 14 14 00/W048 58 06 00
7A	S16 14 21.06/W048 58 10.02	3735'	15	S16 14 15 00/W048 58 04 00
7B	S16 14 21.06/W048 58 10.02	3735'	16	S16 14 13 00/W048 58 05 00
8A	S16 14 21.06/W048 58 09.06	3735'	17	S16 14 14 00/W048 58 03 00
8B	S16 14 21.06/W048 58 09.06	3735'	18	S16 14 13 00/W048 58 04 00
9A	S16 14 21.00/W048 58 09.06	3735'	19	S16 14 13 00/W048 58 02 00
9B	S16 14 21.00/W048 58 09.06	3735'	20	S16 14 12 00/W048 58 04 00
10A	S16 14 20.04/W048 58 09.00	3735'	21	S16 14 13 00/W048 58 02 00
10B	S16 14 20.04/W048 58 09.00	3735'	22	S16 14 11 00/W048 58 03 00
11A	S16 14 20.04/W048 58 09.00	3735'	23	S16 14 12 00/W048 58 01 00
11B	S16 14 20.04/W048 58 09.00	3735'	24	S16 14 10 00/W048 58 03 00
12A	S16 14 19.08/W048 58 08.04	3735'	25	S16 14 11 00/W048 58 00 00
12B	S16 14 19.08/W048 58 08.04	3735'	26	S16 14 09 00/W048 58 02 00
13A	S16 14 19.02/W048 58 08.04	3735'	27	S16 14 10 00/W048 58 00 00
13B	S16 14 19.08/W048 58 08.04	3735'	28	S16 14 09 00/W048 58 01 00
14A	S16 14 19.02/W048 58 07.08	3735'	29	S16 14 10 00/W048 57 59 00
14B	S16 14 19.02/W048 58 07.08	3735'	30	S16 14 08 00/W048 58 01 00
			31	S16 14 09 00/W048 57 59 00
			32	S16 14 07 00/W048 58 00 00
			33	S16 14 08 00/W048 57 58 00
			34	S16 14 06 00/W048 57 59 00
			35	S16 14 08 00/W048 57 58 00
			36	S16 14 06 00/W048 57 59 00
			37	S16 14 06 00/W048 57 57 00
			38	S16 14 05 00/W048 57 58 00
INS COORDINATES				
PONTO SPOT	COORDENADAS COORDINATES			
1	S16 14.32 / W048 58.14			
2	S16 14.37 / W048 58.18			

CHANGES: LAYOUT.