



CODING TABLE

STAR RNAV VACAR 1G RWY 12					GONÇALO DO AMARANTE / Governador Aluizio Alves (SBNT)							SBSG_STAR_00Q		03 JAN 19	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST	VA (°)	Role of the Fix	Navigation Specification
010	VACAR	N	N/A	VACAR	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
020	VACAR	N	N/A	ARPUK	TF	35.89° Mag 14.17° True	N/A	N/A	+17000.00	N/A	N/A	58.95	N/A	OTHER	RNAV 1 or RNP 1
030	VACAR	N	N/A	BIVIV	TF	36.12° Mag 14.60° True	N/A	N/A	+10000.00	N/A	N/A	32.70	N/A	OTHER	RNAV 1 or RNP 1
040	VACAR	N	N/A	IVSIK	TF	55.28° Mag 33.91° True	N/A	N/A	+4000	N/A	N/A	24.30	N/A	IAF	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
VACAR	S 07:39:55.20W 36:10:07.20
ARPUK	S 06:42:29.73W 35:55:34.95
BIVIV	S 06:10:41.16W 35:47:17.59
IVSIK	S 05:50:23.40W 35:33:39.60

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE