



CODING TABLE

Identification				Aerodrome				Chart Code				AIRAC AMDT	
SID RNAV PENSO 1A RWY 11				PORTO ALEGRE / Salgado Filho, INTL (SBPA)				SBPA_SID_020				10 OCT 19	
Seq	Transition	Path Terminator	Navaid / Fix / WPT	Type / Function	Flyover (Y/N)	Navaid	Course Mag (True)	Dist (NM)	Turn (L/R)	IAS (KT)	Altitude (FT)	Gradient (%)	Perform.
RWY 11													
010	Runway	CF	NETPI	---	Y	---	108 (091.3)	5.0	---	-230	---	5.5	RNAV 1 or RNP 1
TRNS PENSO													
010	Enroute	IF	NETPI	---	N	---	---	---	---	---	---	---	---
020	Enroute	TF	NUVUK	---	N	---	026 (008.5)	10.2	---	-230	-6000	---	RNAV 1 or RNP 1
030	Enroute	TF	SILID	---	N	---	026(008.5)	4.4	---	---	+5000	---	RNAV 1 or RNP 1
040	Enroute	TF	OBLOS	---	N	---	023(005.9)	47.4	---	---	---	---	RNAV 1 or RNP 1
050	Enroute	TF	ASBOV	---	N	---	023(005.9)	8.2	---	---	---	---	RNAV 1 or RNP 1
060	Enroute	TF	ANROB	---	N	---	023(006.0)	6.5	---	---	-21000	---	RNAV 1 or RNP 1
070	Enroute	TF	PENSO	---	N	---	024(005.8)	41.0	---	---	---	---	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
NETPI	S 29:59:48.00W 51:03:48.60
NUVUK	S 29:49:39.60W 51:02:04.20
SILID	S 29:45:17.40W 51:01:19.20
OBLOS	S 28:58:11.57W 50:55:45.47
ASBOV	S 28:49:59.89W 50:54:48.01
ANROB	S 28:43:33.83W 50:54:02.34
PENSO	S 28:02:46.80W 50:49:19.20

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
11	S 29:59:41.46 W 51:09:33.80	11.15 ft MSL

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
=	MANDATORY
	RECOMMENDED
SDF	STEP DOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT