



CODING TABLE

IAC VOR X RWY 08					BOA VISTA / Atlas Brasil Cantanhede, INTL (SBBV)							SBBV_IAC_00L		18 JUL 19	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST	VA (°)	Role of the Fix	Navigation Specification
010	APCH	N/A	N/A	BVI	IF	N/A	N/A	N/A	+3000	N/A	N/A	N/A	N/A	IAF	N/A
020	APCH	N/A	BVI	BVI	FC	287.15° Mag 271.66° True	N/A	N/A	+1600	N/A	N/A	7.00	N/A	---	N/A
030	APCH	N/A	BVI	ANROP	CF	71.57° Mag 56.06° True	L	N/A	+1560	N/A	N/A	N/A	N/A	FAF	N/A
010	FINAL	N/A	N/A	ANROP	IF	N/A	N/A	N/A	+1560	N/A	N/A	N/A	N/A	FAF	N/A
020	FINAL	N/A	BVI	BVI02*	CF	71.59° Mag 56.06° True	N/A	N/A	+1020	N/A	N/A	1.77	-3.00	SDF	N/A
030	FINAL	N/A	BVI	BVI	CF	71.61° Mag 56.06° True	N/A	N/A	@311	N/A	N/A	2.16	-3.00	LTP/FTP	N/A
010	MA	N/A	BVI	N/A	CA	71.62° Mag 56.06° True	N/A	N/A	+1500	N/A	N/A	N/A	N/A	---	N/A
020	MA	N/A	BVI	BVI	DF	N/A	L	N/A	+3000	N/A	N/A	N/A	N/A	MAHF	N/A
030	MA	N/A	BVI	BVI	HM	287.13° Mag 271.64° True	R	N/A	+3000	N/A	N/A	N/A	N/A	MAHF	N/A

(*) Fictitious point = for coding purpose only.

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
BVI	N 02:51:07.57W 60:41:12.81
ANROP	N 02:48:19.26W 60:45:21.56
BVI02	N 02:49:18.87W 60:43:53.47

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT