



CODING TABLE

IAC RNAV(GNSS) B RWY 02					GUARATINGUETÁ / Guaratinguetá (SBGW)							SBGW_IAC_00K	10 OCT 19		
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST	VA (°)	Role of the Fix	Navigation Specification
10	APPROACH	N	N/A	GW017	IF	N/A	N/A	N/A	+7000	200	N/A	N/A	N/A	IAF	RNP 1
20	APPROACH	N	N/A	GW018	TF	325.76° Mag 304.12° True	N/A	N/A	+4700	N/A	N/A	5.00	N/A	IF	RNP 1
10	FINAL	N	N/A	GW018	IF	N/A	N/A	N/A	+4700	N/A	N/A	N/A	N/A	IF	RNP 1
20	FINAL	N	N/A	GW019	TF	261.59° Mag 239.99° True	N/A	N/A	+3890	140	N/A	5.00	N/A	FAF	RNP 1
30	FINAL	Y	N/A	GW022	TF	242.67° Mag 221.10° True	N/A	N/A	+2400	140	N/A	5.00	-3.00	MAPT	RNP 1
10	MA	N	N/A	N/A	VA	246.58° Mag 225.02° True	N/A	N/A	+3400	200	N/A	N/A	N/A	N/A	RNP APCH
20	MA	N	N/A	GW017	DF	N/A	L	N/A	+7000	200	N/A	N/A	N/A	MAHF	RNP APCH
30	MA	N	N/A	GW017	HM	70.62° Mag 48.97° True	L	N/A	+7000	200	N/A	4.35	N/A	MAHF	RNP APCH

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
GW018	S 22:38:47.33W 45:04:06.55
GW019	S 22:41:17.98W 45:08:47.38
GW021	S 22:43:34.13W 45:10:55.30
GW022	S 22:45:04.09W 45:12:19.88
GW017	S 22:41:36.41W 44:59:37.50

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT