



CODING TABLE

SID RNAV SAMLU 1A RWY 26				BOA VISTA / Atlas Brasil Cantanhede, INTL (SBBV)							SBBV_SID_00W		18 JUL 19		
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST	VA (°)	Role of the Fix	Navigation Specification
10	RWY	Y	N/A	SAMLU	CF	258.57° Mag 243.03° True	N/A	N/A	N/A	N/A	N/A	3.00	N/A	OTHER	RNP 1
10	OPRAB	N/A	N/A	SAMLU	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNP 1
20	OPRAB	N	N/A	OPRAB	DF	N/A	R	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNP 1
10	ANBIX	N/A	N/A	SAMLU	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNP 1
20	ANBIX	N	N/A	ANBIX	DF	N/A	L	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNP 1
10	KIGOX	N/A	N/A	SAMLU	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNP 1
20	KIGOX	N	N/A	KIGOX	DF	N/A	L	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNP 1
10	DIVRA	N/A	N/A	SAMLU	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNP 1
20	DIVRA	N	N/A	DIVRA	DF	N/A	R	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNP 1
10	ILNER	N/A	N/A	SAMLU	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNP 1
20	ILNER	N	N/A	ILNER	DF	N/A	R	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNP 1
10	PICOM	N/A	N/A	SAMLU	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNP 1
20	PICOM	N	N/A	PICOM	DF	N/A	R	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
SAMLU	N 02:49:04.80W 60:44:43.20
OPRAB	N 03:08:19.22W 61:29:24.59
ANBIX	N 02:11:06.60W 60:37:23.40
KIGOX	N 02:16:01.80W 60:23:54.60
DIVRA	N 03:39:38.40W 60:59:18.00
ILNER	N 03:52:16.20W 60:46:45.60
PICOM	N 03:24:33.60W 60:19:01.80

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
26	N 02:50:26.93 W 60:42:03.05	261.12 ft MSL