



## CODING TABLE

SID RNAV SOFIA 1A RWY 17					BAURU / Bauru - Arealva (SBAE)							SBAE_SID_00D		24 MAY 18	
Seq Num	IAP Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST	VA (°)	Role Of TheFix	Navigation Specification
10	RWY	Y	N/A	AE022	CF	174.33° Mag 153.88° True	N/A	N/A	N/A	N/A	N/A	3.00	1.89	TP	RNAV 1 or RNP 1
20	RWY	N	N/A	SOFIA	TF	244.27° Mag 223.99° True	R	N/A	N/A	N/A	N/A	20.00	N/A	OTHER	RNAV 1 or RNP 1
10	EN ROUTE	N	N/A	SOFIA	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	EN ROUTE	N	N/A	NEVKU	TF	316.02° Mag 296.08° True	R	N/A	N/A	N/A	N/A	48.62	N/A	OTHER	RNAV 1 or RNP 1
10	EN ROUTE	N	N/A	SOFIA	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	EN ROUTE	N	N/A	LUTVI	TF	300.78° Mag 280.93° True	R	N/A	N/A	N/A	N/A	49.78	N/A	OTHER	RNAV 1 or RNP 1
10	EN ROUTE	N	N/A	SOFIA	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	EN ROUTE	N	N/A	DEXOV	TF	261.87° Mag 241.93° True	R	N/A	N/A	N/A	N/A	34.04	N/A	OTHER	RNAV 1 or RNP 1
10	EN ROUTE	N	N/A	SOFIA	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	EN ROUTE	N	N/A	ESAVA	TF	187.12° Mag 166.31° True	N/A	N/A	N/A	N/A	N/A	30.39	1.89	OTHER	RNAV 1 or RNP 1

IDENT	Latitude / Longitude (WGS84) DD:MM:SS.SS
AE022	S 22:12:50.40W 49:02:32.40
SOFIA	S 22:27:17.40W 49:17:30.60
NEVKU	S 22:05:57.38W 50:04:39.55
LUTVI	S 22:17:57.84W 50:10:16.31
DEXOV	S 22:43:25.10W 49:49:56.01
ESAVA	S 22:56:54.23W 49:09:44.73

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
17	S 22:10:07.99 W 49:03:57.78	1960.50 ft MSL

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE