



CODING TABLE

Identification	Aerodrome	Chart Code	AIRAC AMDT
SID RNAV RNAV ISNUV 1A RWY 16	BELO HORIZONTE / Tancredo Neves, INTL (SBCF)	SBCF_SID_01R	26 MAR 20

Seq	Transition	Path Terminator	Navaid / Fix / WPT	Type / Function	Flyover (Y/N)	Navaid	Course Mag (True)	Dist (NM)	Turn (L/R)	IAS (KT)	Altitude (FT)	Gradient (%)	Perform.
RWY 16													
010	Runway	CA	---	---	---	---	161 (138.8)	---	---	---	+4700	---	RNAV 1 or RNP 1
020	Runway	DF	VUPER	---	N	---	---	---	L	---	-9000	---	RNAV 1 or RNP 1
030	Runway	TF	ISNUV	---	N	---	073 (050.7)	10.0	R	---	-10000	---	RNAV 1 or RNP 1
TRNS ANLES													
010	Enroute	IF	ISNUV	---	N	---	---	---	---	---	-10000	---	RNAV 1 or RNP 1
020	Enroute	TF	ANLES	---	N	---	046 (023.4)	21.1	L	---	---	---	RNAV 1 or RNP 1
TRNS KOKSU													
010	Enroute	IF	ISNUV	---	N	---	---	---	---	---	-10000	---	RNAV 1 or RNP 1
020	Enroute	TF	KOKSU	---	N	---	085 (062.2)	17.4	R	---	---	---	RNAV 1 or RNP 1

TRNS SALVI													
010	Enroute	IF	ISNUV	---	N	---	---	---	---	---	-10000	---	RNAV 1 or RNP 1
020	Enroute	TF	ANLES	---	N	---	046 (023.4)	21.1	L	---	---	---	RNAV 1 or RNP 1
030	Enroute	TF	SALVI	---	N	---	042 (019.2)	17.9	L	---	-19000	---	RNAV 1 or RNP 1

TRNS YPT													
010	Enroute	IF	ISNUV	---	N	---	---	---	---	---	-10000	---	RNAV 1 or RNP 1
020	Enroute	TF	ANPEK	---	N	---	110 (087.4)	21.4	R	---	+15000	---	RNAV 1 or RNP 1
030	Enroute	TF	YPT	---	N	---	110 (087.3)	41.5	---	---	---	---	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS	DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)	COD	Meaning
YPT	S 19:27:46.80W 42:28:46.20	16	S 19:39:00.00 W 43:57:13.22	2712.60 ft MSL	+	AT OR ABOVE
VUPER	S 19:37:08.88W 43:43:24.60				-	AT OR BELOW
ISNUV	S 19:30:47.43W 43:35:13.32				=	MANDATORY
ANLES	S 19:11:21.60W 43:26:24.00					RECOMMENDED
SALVI	S 18:54:25.80W 43:20:12.00				SDF	STEPDOWN FIX
KOKSU	S 19:22:38.40W 43:18:58.20				Y	YES
ANPEK	S 19:29:48.30W 43:12:36.87				N	NO
					L	LEFT
					R	RIGHT