



CODING TABLE

STAR RNAV VACAR 1D RWY 12					SÃO GONÇALO DO AMARANTE / Gov Aluizio Alves, INTL (SBSG)							SBSG_STAR_00R		03 JAN 19	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST	VA (°)	Role of the Fix	Navigation Specification
10	ENROUTE	N	N/A	VACAR	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	ENROUTE	N	N/A	SEVIL	TF	49.45° Mag 27.64° True	N/A	N/A	19000	N/A	N/A	42.12	N/A	OTHER	RNAV 1 or RNP 1
30	ENROUTE	N	N/A	ANPED	TF	49.03° Mag 27.59° True	N/A	N/A	N/A	N/A	N/A	61.29	N/A	OTHER	RNAV 1 or RNP 1
40	ENROUTE	N	N/A	NEBUG	TF	348.20° Mag 326.80° True	N/A	-6000	+5000	N/A	N/A	11.44	N/A	OTHER	RNAV 1 or RNP 1
50	ENROUTE	N	N/A	IVSIK	TF	346.45° Mag 325.08° True	N/A	N/A	N/A	N/A	N/A	9.54	N/A	IAF	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
VACAR	S 07:39:55.20W 36:10:07.20
SEVIL	S 07:02:26.40W 35:50:26.40
ANPED	S 06:07:52.20W 35:21:53.40
NEBUG	S 05:58:15.00W 35:28:10.80
IVSIK	S 05:50:23.40W 35:33:39.60

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE