



CODING TABLE

IAC NDB RWY 34					MAXARANGUAPE / Maxaranguape, MIL (SNXX)							SNXX_IAC_00A		12 SEP 19	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	MXN	MXN	IF	N/A	N/A	N/A	+3000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	MXN	MXN	FC	175.94° Mag 154.75° True	N/A	N/A	+1700	-220	N/A	2min	N/A	OTHER	N/A
30	FINAL	N/A	MXN	MXN03*	CF	330.99° Mag 309.80° True	L	N/A	@337.57	N/A	N/A	N/A	N/A	FTP	N/A
10	MA	N/A	MXN	N/A	CA	330.99° Mag 309.80° True	N/A	N/A	+2000	N/A	N/A	N/A	N/A	N/A	N/A
20	MA	N/A	N/A	MXN	DF	N/A	R	N/A	+3000	N/A	N/A	N/A	N/A	MAHF	N/A
30	MA	N/A	MXN	MXN	HM	175.94° Mag 154.75° True	R	N/A	+3000	N/A	N/A	N/A	N/A	MAHF	N/A

(*) Fictitious point = for coding purpose only

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
MXN	S 05:23:10.20W 35:31:51.60
MXN03	S 05:23:34.32W 35:31:22.71

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT