



## CODING TABLE

SID TQA 1A RWY11					PORTO ALEGRE / Salgado Filho, INTL (SBPA)							SBPA_SID_00G		31 JAN 19	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST	VA (°)	Role of the Fix	Navigation Specification
10	RWY	Y	FIG	FIG	CF	108.35° Mag 91.30° True	N/A	N/A	N/A	N/A	N/A	9.58	N/A	OTHER	---
20	RWY	Y	TQA	TQA	CF	44.00° Mag 26.69° True	N/A	-7000	N/A	N/A	N/A	22.17	N/A	OTHER	---
10	BUTOK	Y	N/A	TQA	IF	N/A	N/A	-7000	N/A	N/A	N/A	N/A	N/A	OTHER	---
20	BUTOK	Y	TQA	JUICE	CF	64.31° Mag 46.78° True	N/A	-7000	N/A	N/A	N/A	16.39	N/A	OTHER	---
30	BUTOK	Y	TQA	BUTOK	CF	63.87° Mag 46.01° True	N/A	N/A	N/A	N/A	N/A	25.32	N/A	OTHER	---
10	JUICE	Y	N/A	TQA	IF	N/A	N/A	-7000	N/A	N/A	N/A	N/A	N/A	OTHER	---
20	JUICE	Y	TQA	JUICE	CF	64.31° Mag 46.78° True	N/A	-7000	N/A	N/A	N/A	16.39	N/A	OTHER	---

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
FIG	S 29:59:53.44W 50:58:31.96
TQA	S 29:40:06.60W 50:46:54.60
ELATE	S 29:37:33.60W 50:31:37.20
GETVI	S 29:22:14.40W 50:05:32.40
JUICE	S 29:28:52.20W 50:33:12.00
BUTOK	S 29:11:16.20W 50:12:19.80

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
11	S 29:59:41.46 W 51:09:33.80	11.25 ft MSL