



## CODING TABLE

STAR RNAV DADPU 1C RWY 16R					NATAL /Augusto Severo, MIL (SBNT)							SBNT_STAR_01Q		03 JAN 19	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST	VA (°)	Role of the Fix	Navigation Specification
10	ENROUTE	N	N/A	DADPU	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	ENROUTE	N	N/A	ASIRO	TF	159.50° Mag 138.20° True	N/A	N/A	N/A	N/A	N/A	26.70	N/A	OTHER	RNAV 1 or RNP 1
30	ENROUTE	N	N/A	KUBTO	TF	140.21° Mag 118.87° True	N/A	N/A	+4000	N/A	N/A	43.85	N/A	OTHER	RNAV 1 or RNP 1
40	ENROUTE	N	N/A	NT376	TF	136.09° Mag 114.74° True	N/A	N/A	+4000	N/A	N/A	12.40	N/A	IAF	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
DADPU	S 05:02:10.39W 36:34:59.19
ASIRO	S 05:22:11.10W 36:17:08.36
KUBTO	S 05:43:28.80W 35:38:38.40
NT376	S 05:48:41.80W 35:27:20.60

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE