



## CODING TABLE

IAC ILS Y RWY 11L					BRASÍLIA / Pres. Juscelino Kubitschek, INTL (SBBR)						SBBR_IAC_02B		10 OCT 19		
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	N/A	LUVLA	IF	N/A	N/A	N/A	+7000.00	N/A	N/A	N/A	N/A	IAF	RNAV 1 or RNP 1
20	APCH	N/A	N/A	MOVDO	TF	33.78° Mag 12.13° True	N/A	N/A	+6500.00	N/A	N/A	6.88	N/A	IF	RNAV 1 or RNP 1
10	APCH	N/A	N/A	KOGNO	IF	N/A	N/A	N/A	+7000.00	N/A	N/A	N/A	N/A	IAF	RNAV 1 or RNP 1
20	APCH	N/A	N/A	BR038	TF	194.23° Mag 172.60° True	N/A	N/A	+6500.00	N/A	N/A	3.72	N/A	OTHER	RNAV 1 or RNP 1
30	APCH	N/A	N/A	MOVDO	TF	136.77° Mag 115.12° True	N/A	N/A	+6500.00	N/A	N/A	3.96	N/A	IF	RNAV 1 or RNP 1
10	FINAL	N/A	N/A	MOVDO	IF	N/A	N/A	N/A	+6500.00	N/A	N/A	N/A	N/A	IF	N/A
20	FINAL	N/A	IBR	DIBUB	CF	107.88° Mag 86.19° True	N/A	N/A	R6200.00	N/A	N/A	5.00	N/A	FAF	N/A
30	FINAL	N/A	IBR	RW11L	CF	107.89° Mag 86.16° True	N/A	N/A	@3505.60	N/A	N/A	8.35	-3.04	LTP	N/A
10	MA	N/A	N/A	N/A	CA	107.68° Mag 85.94° True	N/A	N/A	+5000.00	N/A	N/A	N/A	N/A	N/A	RNAV 1 or RNP 1
20	MA	Y	N/A	BR042	DF	N/A	L	N/A	+6000.00	N/A	N/A	N/A	N/A	MAHF	RNAV 1 or RNP 1
30	MA	Y	N/A	BR042	HM	258.16° Mag 236.40° True	R	N/A	+6000.00	N/A	N/A	1.00 min	N/A	MAHF	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
MOVDO	S 15:52:41.67W 48:09:28.55
DIBUB	S 15:52:22.00W 48:04:17.96
RW11L	S 15:51:48.86W 47:55:39.22
BR042	S 15:45:54.10W 47:51:54.10
LUVLA	S 15:59:26.73W 48:10:58.58
KOGNO	S 15:47:17.80W 48:13:41.66
BR038	S 15:51:00.31W 48:13:11.82

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT