



CODING TABLE

This table supplements information contained in the chart to which it is associated. In spite of the fact the classification of waypoints (fly-by / flyover), courses, distances, altitudes, level and speed restrictions are mandatory, the providers may use the information as they find appropriate in order to code procedures. In other words, in case any particular coding is applied, it is mandatory for it to reflect the procedure published in the chart.

Identification				Aerodrome				Chart Code			AIRAC AMDT		
STAR RNAV BUXEV 2A – TIMVI 2A RWY 11				PORTO ALEGRE / Salgado Filho, INTL (SBPA)				SBPA_STAR_02J			29 MAR 18		
Seq	Transition	Path Terminator	Navaid / Fix / WPT	Type / Function	Flyover (Y/N)	REC Navaid	Course Mag (True)	Dist (NM)	Turn	IAS (KT)	Altitude (FT)	Vertical Angle	Perform.
TIMVI 1A													
010	Enroute	IF	TIMVI	---	N	---	---	---	---	---	---	---	---
020	Enroute	TF	GIGNO	---	N	---	242 (224.1)	49.7	---	---	+15000	---	RNAV 1 or RNP 1
030	Enroute	TF	KOTUB	---	N	---	242 (224.5)	34.0	---	---	---	---	RNAV 1 or RNP 1
040	Enroute	TF	PA049	---	N	---	288 (271.3)	9.3	R	---	+9000	---	RNAV 1 or RNP 1
050	Enroute	TF	OGVUV	IAF	N	---	288 (271.4)	16.0	---	---	+4000	---	RNAV 1 or RNP 1
BUXEV 1A													
TRNS EKUTI													
010	Enroute	IF	EKUTI	---	N	---	---	---	---	---	---	---	---
020	Enroute	TF	DABUL	---	N	---	235 (217.0)	21.4	---	---	-28000	---	RNAV 1 or RNP 1
030	Enroute	TF	SUPNI	---	N	---	235 (217.2)	7.4	---	---	---	---	RNAV 1 or RNP 1
040	Enroute	TF	PUDAK	---	N	---	235 (217.3)	11.3	---	---	+22000	---	RNAV 1 or RNP 1
050	Enroute	TF	CXS	---	N	---	234 (217.3)	14.8	L	---	-17000	---	RNAV 1 or RNP 1
060	Enroute	TF	BUXEV	---	N	---	215 (197.9)	26.8	L	---	+7000 W -8000	---	RNAV 1 or RNP 1

TRNS EAGLE													
010	Enroute	IF	EAGLE	---	N	---	---	---	---	---	---	---	---
020	Enroute	TF	BUXEV	---	N	---	154 (137.2)	34.4	---	---	+7000 W -8000	---	RNAV 1 or RNP 1
010	Common	IF	BUXEV	---	N	---	---	---	---	---	---	---	---
020	Common	TF	ANBIV	---	N	---	215 (197.9)	5.8	---	---	+6000 W -7000	---	RNAV 1 or RNP 1
010	Runway	IF	ANBIV	---	N	---	---	---	---	---	---	---	---
020	Runway	TF	OGVUV	IAF	N	---	206 (188.8)	10.9	L	---	+4000	---	RNAV 1 or RNP 1

IDENT	Latitude / Longitude (WGS84) DD:MM:SS.SS
TIMVI	S 28:54:04.28W 49:48:51.64
KOTUB	S 29:54:18.60W 50:55:32.40
PA049	S 29:54:06.52W 51:06:17.97
CXS	S 29:11:53.01W 51:11:19.08
EKUTI	S 28:28:00.90W 50:33:36.76
DABUL	S 28:45:11.91W 50:48:15.94
PUDAK	S 29:00:04.75W 51:01:05.94
BUXEV	S 29:37:29.65W 51:20:46.03
ANBIV	S 29:42:58.95W 51:22:47.94
EAGLE	S 29:12:10.20W 51:47:25.80
OGVUV	S 29:53:43.80W 51:24:42.60
GIGNO	S 29:29:56.15W 50:28:12.64
SUPNI	S28:51:05.32 W50:53:20.56

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
=	MANDATORY
	RECOMMENDED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
W	WINDOW