



CODING TABLE

SID RNAV EROXU 1A RWY 30				PRESIDENTE PRUDENTE / Presidente Prudente (SBDN)								SBDN_SID_00N	04 JAN 18		
Seq Num	IAP Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude ft	Lower Limit Altitude ft	Speed Limit kt	Speed Limit Description	TM DST NM	VA °	Role Of TheFix	Navigation Specification
10	Runway	N	N/A	EROXU	CF	297.70° Mag 278.58° True	N/A	N/A	N/A	N/A	N/A	5.00	N/A	TP	RNP 1
10	Enroute		N/A	EROXU	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	TP	RNP 1
20	Enroute	N	N/A	XOLUG	TF	349.75° Mag 330.76° True	N/A	N/A	N/A	N/A	N/A	46.45	N/A	OTHER	RNP 1
10	Enroute		N/A	EROXU	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNP 1
20	Enroute	N	N/A	ROKOR	TF	310.79° Mag 292.05° True	N/A	N/A	N/A	N/A	N/A	45.02	N/A	OTHER	RNP 1
30	Enroute	N	N/A	SINIL	TF	281.93° Mag 263.57° True	N/A	N/A	N/A	N/A	N/A	33.64	N/A	OTHER	RNP 1
10	Enroute		N/A	EROXU	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	TP	RNP 1
20	Enroute	N	N/A	NUXAL	TF	320.21° Mag 301.43° True	N/A	N/A	N/A	N/A	N/A	47.28	N/A	OTHER	RNP 1

IDENT	Latitude / Longitude (WGS84) DD:MM:SS.SS
XOLUG	S 21:29:02.72W 51:55:49.73
ROKOR	S 21:52:49.33W 52:16:18.80
SINIL	S 21:56:35.52W 52:52:11.29
EROXU	S 22:09:40.70W 51:31:21.77
NUXAL	S 21:45:01.75W 52:14:49.72

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
30	S 22:10:25.46 W 51:26:02.15	1411.52 ft

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE