



CODING TABLE

IAC RNAV (RNP) R RWY 06					VITÓRIA/Eurico de Aguiar Salles (SBVT)							SBVT_IAC_02H		08 NOV 18	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	N/A	VT032	IF	N/A	N/A	N/A	+4000	N/A	N/A	N/A	N/A	IAF	RNP 1.0
20	APCH	N	N/A	VT086	TF	180.17° Mag 156.35° True	N/A	N/A	+3500	N/A	N/A	3.47	N/A	N/A	RNP 1.0
30	APCH	N	N/A	VT088	RF	N/A	L	N/A	+3000	N/A	N/A	6.61	N/A	IF	RNP 1.0
N/A	N/A	N/A	N/A	VT087	N/A	N/A	N/A	N/A	N/A	N/A	N/A	ARC RADIUS 4.10	N/A	N/A	N/A
10	APCH	N	N/A	VT014	IF	N/A	N/A	N/A	+4000	N/A	N/A	N/A	N/A	IAF	RNP 1.0
20	APCH	N	N/A	VT088	TF	087.81° Mag 063.96° True	N/A	N/A	+3000	N/A	N/A	5.00	N/A	IF	RNP 1.0
10	FINAL	N/A	N/A	VT088	IF	N/A	N/A	N/A	+3000	N/A	N/A	N/A	N/A	IF	RNP 0.3
20	FINAL	N	N/A	VT089	RF	N/A	L	N/A	+2000	N/A	N/A	5.47	N/A	N/A	RNP 0.3
30	FINAL	N	N/A	VT091	TF	011.47° Mag 347.61° True	N/A	N/A	N/A	N/A	N/A	1.88	N/A	FAF	RNP 0.3
40	FINAL	N	N/A	VT092	RF	N/A	R	N/A	N/A	N/A	N/A	2.17	-3.20	FROP	RNP 0.1
N/A	N/A	N/A	N/A	VT093	N/A	N/A	N/A	N/A	N/A	N/A	N/A	ARC RADIUS 2.80	N/A	N/A	N/A
50	FINAL	Y	N/A	RWY06	TF	055.72° Mag 031.86° True	N/A	N/A	@ 63	N/A	N/A	N/A	-3.20	LTP	RNP 0.1
10	MA	N	N/A	VT094	TF	055.72° Mag 031.86° True	N/A	N/A	N/A	220	-	7.74	N/A	N/A	RNP 1.0
20	MA	N	N/A	VT096	RF	N/A	R	N/A	N/A	220	-	10.90	N/A	N/A	RNP 1.0
N/A	N/A	N/A	N/A	VT097	N/A	N/A	N/A	N/A	N/A	N/A	N/A	ARC RADIUS 3.50	N/A	N/A	N/A
30	MA	N	N/A	VT084	TF	234.18° Mag 210.32° True	N/A	N/A	N/A	N/A	N/A	18.21	N/A	N/A	RNP 1.0
40	MA	N	N/A	VT014	TF	295.80° Mag 271.97° True	N/A	N/A	N/A	N/A	N/A	8.65	N/A	N/A	RNP 1.0
50	MA	N	N/A	VT014	HM	087.81° Mag 063.96° True	R	N/A	+4000	N/A	N/A	1mim	N/A	N/A	RNP 1.0

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
VT014	S 20:28:39.40W 40:25:54.00
VT032	S 20:21:12.91W 40:28:30.63
VT086	S 20:24:24.52W 40:27:01.65
VT088	S 20:26:27.28W 40:21:06.86
VT087	S 20:22:45.41W 40:23:01.79
VT089	S 20:21:51.89W 40:18:46.18
VT091	S 20:20:01.47W 40:19:12.20
VT092	S 20:17:55.86W 40:18:49.52
VT093	S 20:19:24.86W 40:16:17.70
VT094	S 20:09:16.12W 40:13:07.46
VT096	S 20:12:53.51W 40:06:44.95
VT097	S 20:11:07.27W 40:09:57.78
VT084	S 20:28:57.10W 40:16:41.67
RWY06	S 20:15:52.34 W 40:17:28.16

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT

MISSED APPROACH SEGMENT																
Track	Bank Angle(°)		TWC (KT)		IAS (KT)		D_{MASRNP} (NM)		TrD (NM)		Gradient (%)		RNP (NM)		TP Altitude (FT)	
	Used /	STD	Used /	STD	Used /	STD	Used /	STD	Used /	STD	Used /	STD	Used /	STD	Used /	STD
ALL PARAMETERS ARE ACCORDING TO ICAO DOCUMENTS																

COD	Meaning
STD	Value according to ICAO Documents
TWC	Tail Wind Component
IAS	Indicated Air Speed
D _{frop}	Distance FROP-THEL
FROP	Final Roll-Out Point
TrD	Track Distance (Needed to comply turns)
TP Altitude	Turning Point Altitude
THEL	Threshold elevation
D _{MASRNP}	Maximum distance of RNP navigation accuracy (requirement less than 1.0 NM in the missed approach)