



CODING TABLE

IAC ILS S RWY 15					RIO DE JANEIRO / Galeão – Antônio Carlos Jobim, INTL (SBGL)							SBGL_IAC_040		23 MAY 19	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST	VA (°)	Role of the Fix	Navigation Specification
10	APPROACH	N	N/A	UTBOM	IF	N/A	N/A	N/A	+6300	N/A	N/A	N/A	N/A	IAF	RNAV 1
20	APPROACH	N	N/A	DOOPK	TF	148.50° Mag 125.50° True	N/A	N/A	+5000	N/A	N/A	2.70	N/A	OTHER	RNAV 1
30	APPROACH	N	N/A	EGBAT	TF	148.60° Mag 125.59° True	N/A	N/A	+3300	N/A	N/A	4.80	N/A	IF	RNAV 1
10	APPROACH	N	N/A	EGDUT	IF	N/A	N/A	N/A	+6300	N/A	N/A	N/A	N/A	IAF	RNAV 1
20	APPROACH	N	N/A	RJ001	TF	89.75° Mag 66.92° True	N/A	N/A	+4700	N/A	N/A	4.80	N/A	OTHER	RNAV 1
30	APPROACH	N	N/A	EGBAT	TF	89.72° Mag 66.86° True	N/A	N/A	+3300	N/A	N/A	4.19	N/A	IF	RNAV 1
10	FINAL	N	N/A	EGBAT	IF	N/A	N/A	N/A	+3300	N/A	N/A	N/A	N/A	IF	---
20	FINAL	N	IJB	ROBOL	CF	148.60° Mag 125.60° True	N/A	N/A	+1710	N/A	N/A	4.96	N/A	FAF	---
30	FINAL	N	IJB	RWY15	CF	148.57° Mag 125.57° True	N/A	N/A	@68	N/A	N/A	5.11	-3.00	LTP/FTP	---
10	MA	N	N/A	OBKEP	DF	N/A	N/A	N/A	+1800	N/A	N/A	6.25	N/A	OTHER	RNP APCH
20	MA	N	N/A	UTKUP	TF	114.76° Mag 91.82° True	N/A	N/A	+2700	N/A	N/A	3.00	N/A	OTHER	RNP APCH
30	MA	N	N/A	GL079	TF	114.70° Mag 91.71° True	N/A	N/A	=4000	N/A	N/A	8.00	N/A	OTHER	RNP APCH
40	MA	N	N/A	SISER	TF	114.69° Mag 91.66° True	N/A	N/A	=5000	N/A	N/A	7.00	N/A	OTHER	RNP APCH
50	MA	N	N/A	SISER	HM	294.69° Mag 271.66° True	L	N/A	+5000	N/A	N/A	1.00 min	N/A	MAHF	RNP APCH

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
EGBAT	S 22:42:54.60W 43:24:37.20
ROBOL	S 22:45:48.19W 43:20:15.29
RWY15	S 22:48:47.14W 43:15:45.57
OBKEP	S 22:49:11.04W 43:10:11.14
UTKUP	S 22:49:16.80W 43:06:56.40
GL079	S 22:49:31.40W 42:58:17.05
SISER	S 22:49:43.80W 42:50:42.60
UTBOM	S 22:38:31.80W 43:31:13.20
DOOPK	S 22:40:06.26W 43:28:50.56
EGDUT	S 22:46:27.00W 43:33:34.20
RJ001	S 22:44:33.70W 43:28:47.36

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT