



CODING TABLE

SID RNAV KOTVU 2C RWY 11R					BRASÍLIA / Pres. Juscelino Kubitschek, INTL (SBBR)							SBBR_SID_02W		27 FEB 20	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	RUNWAY	N/A	N/A	N/A	VA	107.94° Mag 86.20° True	N/A	N/A	+4100.00	N/A	N/A	N/A	N/A	N/A	RNAV 1 or RNP 1
20	RUNWAY	N	N/A	KOTVU	CF	101.00° Mag 79.19° True	N/A	-9000.00	N/A	N/A	N/A	N/A	N/A	N/A	RNAV 1 or RNP 1
30	RUNWAY	N	N/A	ESBUX	TF	356.58° Mag 334.79° True	N/A	-10000.00	N/A	N/A	N/A	11.48	N/A	N/A	RNAV 1 or RNP 1
40	RUNWAY	N	N/A	PANOK	TF	56.35° Mag 34.44° True	N/A	N/A	+21000.00	N/A	N/A	37.24	N/A	N/A	RNAV 1 or RNP 1
10	PEDAL	N/A	N/A	PANOK	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	RNAV 1 or RNP 1
20	PEDAL	N	N/A	PEDAL	TF	85.86° Mag 63.73° True	N/A	N/A	N/A	N/A	N/A	42.33	N/A	N/A	RNAV 1 or RNP 1
10	FLASH	N/A	N/A	PANOK	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	RNAV 1 or RNP 1
20	FLASH	N	N/A	FLASH	TF	98.96° Mag 76.80° True	N/A	N/A	N/A	N/A	N/A	43.93	N/A	N/A	RNAV 1 or RNP 1
10	ORATE	N/A	N/A	PANOK	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	RNAV 1 or RNP 1
20	ORATE	N	N/A	ORATE	TF	108.27° Mag 86.09° True	N/A	N/A	N/A	N/A	N/A	46.66	N/A	N/A	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
KOTVU	S 15:51:01.70W 47:43:30.80
ESBUX	S 15:40:35.40W 47:48:35.40
PANOK	S 15:09:45.60W 47:26:45.60
PEDAL	S 14:51:00.00W 46:47:30.60
FLASH	S 14:59:45.60W 46:42:32.40
ORATE	S 15:06:39.00W 46:38:37.80

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
11R	S 15:52:43.62 W 47:54:38.33	3422.05 ft MSL